





NDS3306I 6 in 1 ISDB-T Modulator User Manual



DEXIN DIGITAL TECHNOLOGY CORP. LTD.

Add: No. 10 and 12, Wuxing Fourth Road, Wuhou District Chengdu 610045, Sichuan, PR China
www.dsdvb.com/english Tel: +86-028-85550524 Fax: +86-028-85585255 Email: sunyu@dsdvb.com

About This Manual

Intended Audience

This user manual has been written to help people who have to use, to integrate and to install the product. Some chapters require some prerequisite knowledge in electronics and especially in broadcast technologies and standards.

Disclaimer

No part of this document may be reproduced in any form without the written permission of the copyright owner.

The contents of this document are subject to revision without notice due to continued progress in methodology, design and manufacturing. DEXIN shall have no liability for any error or damage of any kind resulting from the use of this document.

Copy Warning

This document includes some confidential information. Its usage is limited to the owners of the product that it is relevant to. It cannot be copied, modified, or translated in another language without prior written authorization from DEXIN.

Directory

| | |
|---|-----------|
| Chapter 1 Product Overview..... | 1 |
| 1.1 Outline | 1 |
| 1.2 Inner Structure | 1 |
| 1.5 Specifications..... | 2 |
| Chapter 2 Physical Presentational Statement..... | 2 |
| 2.1 Front panel Illustration: | 4 |
| 2.2 Rear panel Illustration:..... | 4 |
| Chapter 3 Installation Guide..... | 5 |
| 3.1 Acquisition Check..... | 5 |
| 3.2 Installation Preparation..... | 5 |
| Chapter 4 Web NMS Management..... | 8 |
| 4.1 Login | 8 |
| 4.2 Operation..... | 8 |
| Chapter 5 Troubleshooting..... | 20 |

Chapter 1 Product Overview


1.1 Outline

NDS3306I 6 in 1 ISDB-T modulator is the latest generational Mux-modulating device developed by DEXIN. It has 6 multiplexing channels and 6 (ISDB-Tb) modulating channels, and supports maximum 192 IP input through the 3 GE ports and 6 non-adjacent carriers (50MHz~960MHz) output through the RF output interface. The device is also characterized with high integrated level, high performance and low cost. This is very adaptable to newly generation DTV broadcasting system.


1.2 Key Features

- 3 GE ports (max 192 IP in):
 - Data1 & Data2 bi-directional ports, max 192 IP in, 6 IP out
 - Data port (located on front panel), max 128 IP in
- Max 840Mbps for each GE input
- Supports accurate PCR adjusting
- Supports CA filtering, PID remapping and PSI/SI editing
- Supports up to 180 PIDS remapping per channel
- Support 6 IP output through Data1 & Data2 over UDP/RTP/RTSP
- 6 non-adjacent carriers output, compliant to ISDB-Tb (ARIB STD-B31)
- Support Web-based Network management

1.3 Inner Structure



1.4 Carrier Setting Illustration



1.5 Specifications

| | | |
|------------------------------|--------------------|--|
| Input | Input | Max 192 IP input through 3 (front-panel Data port, Data 1 and Data 2) 100/1000M Ethernet Port (SFP interface optional). Each Data1 or Data 2 port can input max 192 IP, while front-panel Data port can input max 128 IP |
| | Transport Protocol | TS over UDP/RTP, unicast and multicast, IGMP V2/V3 |
| | Transmission Rate | Max 840Mbps for each GE input |
| Mux | Input Channel | 192 |
| | Output Channel | 6 |
| | Max PIDs | 180 per channel |
| | Functions | PID remapping (auto/manually optional) |
| | | PCR accurate adjusting |
| | | PSI/SI table automatically generating |
| Modulation Parameters | Standard | ARIB STD-B31 |
| | Bandwidth | 6M |
| | Constellation | QPSK, 16QAM, 64QAM |
| | Guard Interval | 1/32, 1/16, 1/8, 1/4 |
| | Transmission Mode | 2K, 4K, 8K |
| | Code rate | 1/2, 2/3, 3/4, 5/6, 7/8 |
| | MER | ≥40dB |
| | RF frequency | 50~960MHz, 1KHz step |
| | RF output level | -20dBm~+10dBm(87~117dbμV), 0.1dB stepping |
| RF Output | Interface | 1 F typed output port for 6 carriers, 75Ω |


| | | |
|------------------|--|--|
| | | impedance |
| | ACLR | -50 dBc |
| TS output | 6 IP output over UDP/RTP/RTSP, unicast/multicast, 2 (Data1& Data2) 100/1000M Ethernet Ports | |
| System | Network management software (NMS) supporting | |
| General | Demission | 420mm×440mm×44.5mm (W×L×H) |
| | Weight | 3kg |
| | Temperature | 0~45℃(operation), -20~80℃(storage) |
| | Power Supply | AC 100V±10%, 50/60Hz or AC 220V±10%, 50/60Hz |
| | Consumption | 15.4W |

Chapter 2 Physical Presentational Statement

2.1 Front panel Illustration:



2.2 Rear Panel Illustration:



| | |
|---|--|
| 1 | NMS/CAS: network management port and CA data port |
| 2 | DATA input port |
| 3 | Indicators |
| 4 | Grounding |
| 5 | Power switch |
| 6 | AC Power Socket |
| 7 | RF output port |
| 8 | Reset IP: Reset webmaster IP address, recover it to default IP address |
| 9 | Data Input /Output 1/2 |

Chapter 3 Installation Guide

3.1 Acquisition Check

When user opens the package of the device, it is necessary to check items according to packing list. Normally it should include the following items:

- NDS3306I 6 in 1 ISDB-T Modulator
- User's Manual
- Power Cord

If any item is missing or mismatching with the list above, please contact local dealer.


3.2 Installation Preparation

When users install device, please follow the below steps. The details of installation will be described at the rest part of this chapter. Users can also refer rear panel chart during the installation.

The main steps of the installation include:

- Checking the possible device missing or damage during the transportation
- Preparing relevant environment for installation
- Installing NDS3306I 6 in 1 ISDB-T Modulator
- Connecting signal cables
- Connecting communication port (if it is necessary)

3.2.1 Device's Installation Flow Chart Illustrated as follows:



3.2.2 Environment Requirement

| Item | Requirement |
|-------------------------|--|
| Machine Hall Space | When user installs machine frame array in one machine hall, the distance between 2 rows of machine frames should be 1.2~1.5m and the distance against wall should be no less than 0.8m. |
| Machine Hall Floor | Electric Isolation, Dust Free Volume resistivity of ground anti-static material: $1 \times 10^7 \sim 1 \times 10^{10} \Omega$, Grounding current limiting resistance: 1M (Floor bearing should be greater than 450Kg/m ²) |
| Environment Temperature | 5~40°C(sustainable), 0~45°C(short time) installing air-conditioning is recommended |
| Relative Humidity | 20%~80% sustainable 10%~90% short time |
| Pressure | 86~105KPa |
| Door & Window | Installing rubber strip for sealing door-gaps and dual level glasses for window |
| Wall | It can be covered with wallpaper, or brightness less paint. |
| Fire Protection | Fire alarm system and extinguisher |
| Power | Requiring device power, air-conditioning power and lighting power are independent to each other. Device power requires AC power 220V $\pm 10\%$ 50/60Hz or 110V $\pm 10\%$ 50/60Hz. Please carefully check before running. |

3.2.3 Grounding Requirement

- All function modules' good grounding is the basis of reliability and stability of devices. Also, they are the most important guarantee of lightning arresting and interference rejection. Therefore, the system must follow this rule.
- Coaxial cables' outer conductor and isolation layer should keep proper electric conducting with the metal housing of device.

- Grounding conductor must adopt copper conductor in order to reduce high frequency impedance, and the grounding wire must be as thick and short as possible.
- Users should make sure the 2 ends of grounding wire well electric conducted and be antirust.
- It is prohibited to use any other device as part of grounding electric circuit
- The area of the conduction between grounding wire and device's frame should be no less than 25mm^2 .

3.2.4 Frame Grounding

All the machine frames should be connected with protective copper strip. The grounding wire should be as short as possible and avoid circling. The area of the conduction between grounding wire and grounding strip should be no less than 25mm^2 .

3.2.5 Device Grounding

Connecting the device's grounding rod to frame's grounding pole with copper wire.

3.3 Wire's Connection

3.3.1 Power cord connection

The power socket is located on the right of rear panel, and the power switch is on the left of front panel. User can plug one end of the power cord to the socket and insert the other end to AC power. When the device solely connects to protective ground, it should adopt independent way, say, share the same ground with other devices. When the device adopts united way, the grounding resistance should be smaller than 1Ω .

⚠ **Caution:** Before connecting power cord to NDS3306I 6 in 1 ISDB-T Modulator, user should set the power switch to "OFF".

3.3.2 Signal and NMS Cable Connection

The signal connections include the connection of input signal cable and the connection of output signal cable.

Chapter 4 Web NMS Management

This device does not support the LCD operation, and the modification can only be operated under Web NMS.

4.1 Login

The default IP address of this device is **192.168.0.136**.

Connect the PC (Personal Computer) and the device with a net cable, and use ping command to confirm they are on the same network segment. For instance, the PC IP address is 192.168.99.252, we then change the device IP to 192.168.99.xxx (xxx can be 0 to 255 except 252 to avoid IP conflict).

Launch the web browser and input the device IP address in the browser's address bar and press Enter.

It will display the Login interface as Figure-1. Input the Username and Password (Both the default Username and Password are "admin"). And then click "Login" to start the device setting.




Figure-1

4.2 Operation

4.2.1 Summary

When we confirm the login, it will display the summary interface as Figure-2.




Figure-2

4.2.2 Monitor

Monitor → Input Status:

Clicking “Input Status”, it will display the interface as Figure-3 where users can check the input status of Data1 and Data 2. Users need to add IP in “TS Config” part. Otherwise, it will monitor nothing.




Figure-3

Monitor → Output Status:

Clicking “Output Status”, it will display the interface as Figure-4/5 where users can check

output status of the 6 carriers and 6 IPs. User need to enable the output status in “Modulator” and “IP Stream” part. Otherwise, it will monitor nothing.




Figure-4




Figure-5

4.2.3 Parameters

Parameters → TS Config:

Click “TS Config”, it will display the interface where users can configure the output TS parameters in this interface. (Figure-6)




Figure-6

➤ Output TS X

Clicking “Output TS X”, it will display the interface as Figure-7. Users can select the output TS channels.




Figure-7

➤ Stream Select

Clicking “Stream Select”, it will display the interface where users can choose the programs to Mux out. (Figure-8)


















Figure-8


Configure 'Input Area' and 'Output Area' with buttons in 'Operation Area'. Instructions are as below:

-  : To add input channel which come from Data1 or Data 2 or Data/Module
-  : To edit the input channel
-  : To delete the input channel
-  : To delete all inputs channel
-   : To check input IP lock or not, green means current IP locked
-   : To check current TS overflow or not, red color means current TS overflow, need reduce program
- ☒ CA Filter : Enable/disable the CA Filter function. Clicking the box, user can filter the input CA to avoid disturbing with the device scrambling function.
- ☒ PID Remap : To enable/disable the PID remapping
-  To refresh the input program information
-  To refresh the output program information
-  Select one input program first and click this button to transfer the selected program to the right box to output.
-  Similarly, user can cancel the multiplexed programs from the right box.
-  To select all the input programs
-  To select all the output programs

Parse program To parse programs time limitation of parsing input programs

Program Modification:

The multiplexed program information can be modified by clicking the program in the ‘output’ area. For example, when clicking TV-101 <=CH1_Data1_224.2.2.2:2001 [101] , it triggers a dialog box (Figure 9) where users can input new information.



Program Information [close]

Program From Input: CH1_Module 1 [101]

Service Name: TV-101

Program Number: 1001

Logic Channel Number: 1

Service Type: 0x01

Service Provider: TV-Provider

PMT Descriptor Tag: ☐ 0x00

PMT Descriptor Data: (Hex)

PMT PID: 0x0020

PCR PID: 0x0021

MPEG-4 Video PID: 0x0021


MPEG-1 Audio PID: 0x0022

[Apply] [Close]

Figure-9

➤ General

Clicking “General”, it will display the interface where users can set parameters for each output channel. (Figure-10)



Multi ISDBT Modulation Module

come to use Web Management 2018-11-29 16:18:47 [EN] 中文

TS CONFIG

Output TS 1- Stream Select General PID PASSTHRU

Stream

Output Mode: Mux out

SDT Insert: ☒

Share BAT: ☐

PMT Insert: ☒

TS ID: 1

PCR Correct: ☐

PCR State BW: 1

Character Encoding: NORMAL

PAT Insert: ☒

BAT Insert: ☒

CAT Insert: ☒

Fixed Table Version:

ON ID: 1

PCR Speed BW: 1

Update Program Type: Update by Index

NIT

NIT Insert: Disable

Network Name: network-1

LCN Mode: European

Share NIT: ☐

Version Mode: Automatic

Version Number: 1 (0-31)

TDT/TOT

TDT/TOT Insert: ☒

TOT Descriptor Insert: disable

IPTV Sync(SPTS)

IPTV Sync: ☐

Sync Period: 60 Sec

[Apply]

Figure-10

➤ PID Pass

Clicking “PID Bypass”, it will display the interface as Figure-11 where user can add PIDs to be passed, click the “+” symbol, input current IP channel number, then input current IP

source PID and output PID which is customer needed , then click “set” to apply the parameters.




Figure-11

Parameters → Modulator:

Clicking ‘Modulator’, it will display the interface as Figure-12 where to set RF output parameters.






Figure-12

When users click “quickly config” button, it triggers a dialog box as follow where users can set all channels configuration.



When users click “Channel config” button, it triggers a dialog box as follow where users can set the corresponding channel configuration.



Parameters → IP Stream:


NDS3306I supports TS to output in IP (6*MPTS) format through the DATA port.

Clicking ‘IP Stream’, it will display the interface as Figure-13 where to set IP out parameters.

| # | IP Address | Port | Protocol | Pkt Length | Null PKT Filter | Data1 | Data2 | Status | Bit(Act/Max) |
|---|------------|------|----------|------------|--------------------------|-------------------------------------|--------------------------|--------------------------------------|--------------|
| 1 | 224.2.2.2 | 1001 | UDP | 7 | <input type="checkbox"/> | <input checked="" type="checkbox"/> | <input type="checkbox"/> | ● | 0.0/19.9 M |
| 2 | 224.2.2.2 | 1002 | UDP | 7 | <input type="checkbox"/> | <input checked="" type="checkbox"/> | <input type="checkbox"/> | ● | 0.0/19.9 M |
| 3 | 224.2.2.2 | 1003 | UDP | 7 | <input type="checkbox"/> | <input checked="" type="checkbox"/> | <input type="checkbox"/> | ● | 0.0/19.9 M |
| 4 | 224.2.2.2 | 1004 | UDP | 7 | <input type="checkbox"/> | <input checked="" type="checkbox"/> | <input type="checkbox"/> | ● | 0.0/19.9 M |
| 5 | 224.2.2.2 | 1005 | UDP | 7 | <input type="checkbox"/> | <input checked="" type="checkbox"/> | <input type="checkbox"/> | ● | 0.0/19.9 M |
| 6 | 224.2.2.2 | 1006 | UDP | 7 | <input type="checkbox"/> | <input checked="" type="checkbox"/> | <input type="checkbox"/> | ● | 0.0/19.9 M |

Figure-13

When users click “Quickly Config” button, it triggers a dialog box where users can set all channels MPTS configuration simultaneously.



Quickly Config. [close]

IP Address: 224.2.2.2

Port: 2001

Step: 1

Protocol: UDP

Pkt Length: 7

Null PKT Filter: ☐


TS Output: ☐ Data1 ☐ Data2

Apply Close

Set output IP address

Click to enable the status and select TS out thru Data 1 or Data 2

When users click “Channel Config” button, it triggers a dialog box where users can set corresponding MPTS channel configuration.



Channel 1 Config. [close]

IP Address: 224.2.2.2

Port: 1001

Protocol: UDP

Pkt Length: 7

Null PKT Filter: ☐


TS Output: ☒ Data1 ☐ Data2

Apply Close

4.2.4 System

System → Network:

Clicking ‘Network’, it will display the interface as Figure-14 where to set network parameters.



Multi ISDBT Modulation Module

Management 2018-02-05 [EN | 中文] [Exit]

Summary

Monitor

Parameters

System

Network

Network

NMS

NMS IP Address: 10.0.0.103

NMS Subnet Mask: 255.0.0.0

Web Manage Port: 80

Gateway: 192.168.3.1

MAC Address: 20:3f:12:34:56:78

Apply

Set NMS IP address and login to management device. The default IP address is 192.168.0.136

DATA

IP Address: 192.168.2.136

Subnet Mask: 255.255.255.0

Gateway: 192.168.2.1

MAC Address: 20:4f:12:34:56:78

GE1 Speed: 1.0 Gbps

GE2 Speed: 1.0 Gbps


Apply

Set data port IP address

Figure-14

System → Password:

Clicking “Password”, it will display the screen as Figure-15 where to set the login account and password for the web NMS.




The screenshot shows the 'Multi ISDBT Modulation Module' web interface. The left sidebar contains a menu with sections: Summary, Monitor, Parameters, and System. The 'System' section is expanded, showing options like Network, Password, Configuration, Firmware, Date | Time, and Log. The 'PASSWORD' page is active, displaying a warning message: 'Modify the login name and password to make the device safely. If forget the name or password, you can reset it by keyboard. The default login name and password is "admin". Also please note the capital character and lowercase character.' Below this, there are input fields for 'Current UserName' (pre-filled with 'admin'), 'Current Password', 'New UserName', 'New Password', and 'Confirm New Password'. An 'Apply' button is at the bottom right.

Figure-15

System → Configuration:

Clicking “Configuration”, it will display the screen as Figure-16 where to set your configurations for the device.



The screenshot shows the 'Multi ISDBT Modulation Module' web interface with the 'CONFIGURATION' page active. The left sidebar is the same as in Figure 15, but 'Configuration' is now selected under the 'System' section. The main content area has a title 'CONFIGURATION' and a row of buttons: 'Save', 'Restore', 'Factory Set', 'Backup', and 'Load'. A red dashed box highlights these buttons, with an arrow pointing to a 'Select areas' button. Below this, a warning message states: 'When you change the parameter, you should save configuration, otherwise the new configuration will lost after reboot.' A 'Save config' button is at the bottom right.

Figure-16

System → Firmware:

Clicking “Firmware”, it will display the screen as Figure-17 where to update firmware for the device.



Figure-17

System → Date/Time:

Clicking “Date/Time”, it will display the interface as Figure-18 where users can set date/time for this device.




Figure-18

System → Log:

Clicking “Log”, it will display the screen as Figure-19 where to check the “Log”.




Figure-19

Chapter 5 Troubleshooting

DEXIN's ISO9001 quality assurance system has been approved by CQC organization. For guarantee the products' quality, reliability and stability. All DEXIN products have been passed the testing and inspection before ship out factory. The testing and inspection scheme already covers all the Optical, Electronic and Mechanical criteria which have been published by DEXIN. To prevent potential hazard, please strictly follow the operation conditions.

Prevention Measure

- Installing the device at the place in which environment temperature between 0 to 45 °C
- Making sure good ventilation for the heat-sink on the rear panel and other heat-sink bores if necessary
- Checking the input AC voltage within the power supply working range and the connection is correct before switching on device
- Checking the RF output level varies within tolerant range if it is necessary
- Checking all signal cables have been properly connected
- Frequently switching on/off device is prohibited; the interval between every switching on/off must greater than 10 seconds.

Conditions need to unplug power cord

- Power cord or socket damaged.
- Any liquid flowed into device.
- Any stuff causes circuit short
- Device in damp environment
- Device was suffered from physical damage
- Longtime idle.
- After switching on and restoring to factory setting, device still cannot work properly.
- Maintenance needed